

# INCORE

## USER MANUAL

### SPEC

Battery Capacity:1500 mah

Pod Capacity:2ml

Pod resistance:1.6 ohm

Charging:1A/5V

Voltage for full charging:4.2V

\*please drip few drops of eliquid into the coil before using

### TURN ON/OFF

Press the power button 5 times in 2 second to turn the device on/off. The mid LED light will flash 3 times to confirm your action.

### OVER TIME PROTECTION

When the power button is pressed for more than 10 secs, the output will shut off automatically and the LED will flash 8 times.

### 3 Level output

Press the power button 3 times within a 2 sec period to switch the output mode.

Top light will show the current mode:

Blue light: Power mode

Purple light: Standard mode

Red light: Power saving mode

### LOW RESISTANCE PROTECTION

When the resistance is lower than 0.2 ohm, mid Led red light will flash 3 times without output.

### BATTERY LIFE INDICATOR

The battery indicator will show 3 remaining levels using LED when you press the fire button.

Blue light 100-70%/Purple light 70-30%,Red light under 30%.

When the battery is charging at first, the light of current battery life will flash 3 times and turn on.

When the battery is full of charged mid LED blue light will flash 20 times.

### PASS THROUGH CHARGING

INCORE is able to vape and charging at the same time, will not be apart from you favorite device while it is charging.

Turn right to  
unlock the top cap

